


FIG. 1






FIG. 3




FIG. 4




FIG. 5







FIG. 6











FIG. 13






FIG. 15




FIG. 16

SETTING OF SLIDE & ROTARY SWITCHES

OPERATING STATES	SLIDE SW1	SLIDE SW2	ROTARY SWITCH				REMARKS
			Pos. #	1	2	3	
NORMAL (MODEM)	L	L	0, 2, 4, 6	L	X	X	L
USER SETTING	NORMAL (AT)	H	L	0, 2, 4, 6	L	X	L
	MAINTENANCE (MODEM)	L	H	0, 2, 4, 6	L	X	L
	MAINTENANCE (CPU)	H	H	0, 2, 4, 6	L	X	L
	INITIALIZATION 1	L	L	1, 3, 5, 7	H	X	L
	INITIALIZATION 0	H	L	1, 3, 5, 7	H	X	L
	RESERVED	L	H	1, 3, 5, 7	H	X	L
	TEST MODE	H	H	1, 3, 5, 7	H	X	L
	RESERVED	L	L	8	L	X	H
	TCI (HCl)	H	L	8	L	X	H
	RESERVED	L	H	8	L	X	H
SETTING FOR MAINTENANCE OPERATION							
SETTING FOR SHIPMENT							
TCI (L2CAP)	H	H	8	L	X	X	H
RESERVED	L	L	9	H	X	X	H
RESERVED	H	L	9	H	X	X	H
RESERVED	L	H	9	H	X	X	H
RESERVED	H	H	9	H	X	X	H

FIG. 17